SUPERSCOPE®

SCHEMATIC DIAGRAM FOR MODEL A-260

H101 ~ 104
HT313271T 2SC1327-T

H201 ~ 206
HT313271T 2SC1327-T

H001, 002
HV0000212
SV-3A

H401, 402 HT313271T 2SC1327-T
H403, 404 H415, 416 HT313841F 2SC1384-Q
H405, 406 HV0000705 S3016-R
H407~410 HD1000105 IN60
H411, 412 HT308281C 2SC828-R
H413, 414 HT105641C 2SA564-R
H417, 418 HT106841F 2SA684-Q

H003~006
HT403152B
2SD315-C or D

P100

P200

P400

P700

P300

P500

P600

TAPE
TUNER
PHONO
MIC/AUX
AUX
PRE OUT
MAIN IN
Lch
Rch

BALANCE 500K
VOLUME 250K
TREBLE 50K
BASS 50K

S001-a~F
S001-b~F
S001-c~F
S001-d~F
S001-a~B
S001-b~B
S001-c~B
S001-d~B
S001-e~F
S001-e~B

S002-a ON OFF
S002-b ON OFF
S701 ON LOUDNESS
S003 ON OFF INTER COPPLE

S301-a ON TAPE MONITOR
S301-b MONO STELEO
S301-c ON QUADRA PHASE
S301-d ON REMOTE
S301-e ON MAIN

QUADRA PHASE
MAIN
SPEAKER SYSTEMS
REMOTE

TO LAMP
(FOR CANADA)
(FOR USA)

M001 TAPE
M002 TUNER
M003 PHONO
M004 MIC
M005 AUX

3 PHONO
2 TUNER
4 MIC
1 TAPE
5 AUX

TRANSISTOR CONNECTION (BOTTOM VIEW)
E: EMITTER C: COLLECTOR B: BASE

H101~104, H201~206
H401~404, H411~418
H501

H003~006

H501
HT313841R
2SC1384-R

H502
HD3000213
EQA01-35R

HD2001510
5B-1

www.hifiengine.com