

FOR SUPPLY ±21V..39V = [value]  
READ DOC FOR EB-TA3020 FOR OTHERS SUPPLY

