
SONY
SONY CORP.
TAPE HEAD
PHONO
AUX
LEFT
RIGHT
INPUT
GROUND
TAPE
REC OUT
LEFT
RIGHT
REC/PB
TAPE RECORDER
REMOTE
MAIN
LEFT
RIGHT
SPEAKER
AC OUTLET
AC 117V
75Ω
300Ω
GROUND
AM
FM
ANTENNA