
Front End PC Board (4)
CH4 INPUT
CH3 INPUT
CH2 INPUT
CH1 INPUT
OUT
BATT REMOTE GROUND
+CHASSIS
=EARTH
=SIGNAL
PRIMARY: 3 TURNS 2 X 18ga.
SECONDARY: 6 TURNS 2 X 18ga.
3 TURNS 2 X 18ga.
HIGH PWR (RED)
HIGH CURRENT (GREEN)
SOUNDSTREAM
REF804 AMPS, POWER SUPPLY