


Service Manual

PIONEER
The Art of Entertainment

● GM-X404/X1H/UC



ORDER NO.
CRT1642

BRIDGEABLE FOUR-CHANNEL POWER AMPLIFIER

GM-X404

X1H/UC

GM-X404

X1H/EW,ES

GM-X304

X1H/UC

CONTENTS

1. SAFETY INFORMATION(UC MODEL)	2
2. DISASSEMBLY	2
3. ELECTRICAL PARTS LIST	3
4. CONNECTION DIAGRAM (GM-X404/X1H/UC,EW,ES)	5
5. SCHEMATIC CIRCUIT DIAGRAM (GM-X404/X1H/UC,EW,ES)	7
6. CONNECTION DIAGRAM(GM-X304/X1H/UC)	9
7. SCHEMATIC CIRCUIT DIAGRAM (GM-X304/X1H/UC)	11
8. EXPLODED VIEW	13
9. PACKING METHOD	17
10. OPERATIONS AND CONNECTION (GM-X404/X1H/UC)	18
11. OPERATIONS AND CONNECTION (GM-X304/X1H/UC)	21

SPECIFICATIONS

Power source	14.4 V DC (10.8 — 15.6 V allowable)
Grounding system	Negative type
Current consumption	18 A (at continuous power, 4Ω)
Average current drawn*	5.5 A (4Ω for four channels) 10 A (4Ω for two channel)
Fuse	25 A
Dimensions	206 (W) × 50 (H) × 270 (D) mm [8-1/8 (W) × 2 (H) × 10-5/8 (D) in.]
Weight	2.9 kg (3.3 lbs.) (Leads for wiring not included)
Maximum power output	60 W × 4/140 W × 2 (EIAJ)
Continuous power output	
30 W × 4 (at 14.4V, 4Ω, 20 — 20,000 Hz, 0.08% THD)	
70 W × 2 (at 14.4V, 4Ω, 20 — 20,000 Hz, 0.8% THD)	
35 W × 4 (at 14.4V, 2Ω, 20 — 20,000 Hz, 0.8% THD)	
20 W × 4 (at 12V, 4Ω, 20 — 20,000 Hz, 0.08% THD)	
50 W × 2 (at 12V, 4Ω, 20 — 20,000 Hz, 0.8% THD)	
25 W × 4 (at 12V, 2Ω, 20 — 20,000 Hz, 0.8% THD)	
Load impedance	4Ω (2 — 8Ω allowable)
Frequency response	10 — 50,000 Hz (+0 dB, -1 dB)
Signal-to-noise ratio	108 dB (IHF - A network)
Separation	65 dB (1 kHz)

Low pass filter	Cut off frequency: 80Hz
	Cut off slope: -18 dB/oct
High pass filter	Cut off frequency: 80 Hz
	Cut off slope: -12 dB/oct
Bass boost(GM-X404/X1H/UC,EW,ES) ..	Frequency: 40 — 120 Hz
(GM-X304/X1H/UC)	Frequency: 60 Hz
	Gain: 0 — 12 dB
Input level / impedance	0.4 — 2 V/22 kΩ

These specifications were determined and are presented in accordance with specification standards established by the Ad Hoc Committee of Car Stereo Manufacturers.

Note:

Specifications and the design are subject to possible modification without notice due to improvements.

*Average current drawn

The average current drawn is nearly the maximum current drawn by this unit when an audio signal is input. Use this value when working out total current drawn by multiple power amplifiers.

PIONEER ELECTRONIC CORPORATION

4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan

PIONEER ELECTRONICS SERVICE INC. P.O.Box 1760, Long Beach, California 90801 U.S.A.

PIONEER ELECTRONICS OF CANADA, INC. 300 Allstate Parkway Markham, Ontario L3R 0P2 Canada

PIONEER ELECTRONIC [EUROPE] N.V. Haven 1087 Keetberglaan 1, 9120 Melsele, Belgium

PIONEER ELECTRONICS AUSTRALIA PTY.LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL:[03]580-9911

© PIONEER ELECTRONIC CORPORATION 1995

MC-Service

K-FFP. JAN. 1995 Printed in Japan

GM-X404,X304**1. SAFETY INFORMATION (UC MODEL)****CAUTION**

This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual.

Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely; you should not risk trying to do so and refer the repair to a qualified service technician.

WARNING

Lead in solder used in this product is listed by the California Health and Welfare agency as a known reproductive toxicant which may cause birth defects or other reproductive harm (California Health & Safety Code, Section 25249.5). When servicing or handling circuit boards and other components which contain lead in solder, avoid unprotected skin contact with the solder. Also, when soldering do not inhale any smoke or fumes produced.

2. DISASSEMBLY**● Removing the Case and Panel**

1. Remove four screws, and then remove two cases.
2. Remove two screws, and then remove panel.




Fig.1

● Removing the Amp Unit

1. Remove thirteen screws.
2. Amp unit is unremovable from heat sink if pulled up ordinarily, because silicone compound has been applied between heat sink and subheat sink. To remove amp unit, therefore, follow steps below.
 - a. Unfasten two arbitrary screws securing power transistor.
 - b. Screw them little by little alternately into screw holes A to get amp unit afloat and remove it.
3. Once amp unit has been removed, screws with which power transistor has been secured should be returned to their original position.





Fig.2

5. SCHEMATIC CIRCUIT DIAGRAM(GM-X404/X1H/UC,EW,ES)

AMP UNIT

MC-Service

Amp Assy
Consists of
• Amp Unit
• Isolator Unit



SWITCHES:
AMP UNIT
S101: LPF/HPF SELECT SWITCH...LPF-OFF-HPF
S102: HPF SELECT SWITCH...HPF-OFF
S851: RCA INPUT SELECT SWITCH...2CH-4CH
S901: BFC SWITCH...LOW-HIGH
The underlined indicates the switch position.

NOTE:
⊗ Symbol indicates a resistor.
No differentiation is made between chip resistors and discrete resistors.
⊕ Symbol indicates a capacitor.
No differentiation is made between chip capacitors and discrete capacitors.

Decimal points for resistor and capacitor fixed are expressed as:
2.2-2R2
0.022-R022

CN651				
10	9	8	7	6
5	4	3	2	1

Fig.4

GM-X404,X304

6. CONNECTION DIAGRAM(GM-X304/X1H/UC)

Q908 Q909 Q907 IC, Q 0905 0906	Q601 Q602 Q332	Q205 IC601 Q603 Q316 Q904 Q328	IC602 Q604 Q605	Q608 Q304 Q312	Q607 Q609 Q308 Q302 Q902 Q326 Q611 Q306 Q309	Q610 Q301 Q309	Q613 Q305 Q329	Q612 Q303 Q311 Q313	Q307 Q325	IC302 IC301	Q204 Q202 Q201 Q203 Q331	Q315	IC122 IC123 Q615 Q903 Q327 Q614 IC121 IC151	Q855 Q151 Q152
--------------------------------------	----------------------	---	-----------------------	----------------------	---	----------------------	----------------------	------------------------------	--------------	----------------	-----------------------------------	------	--	----------------------





Fig.5

7. SCHEMATIC CIRCUIT DIAGRAM(GM-X304/X1H/UC)

AMP UNIT

Amp Assy
Consists of
• Amp Unit
• Isolator Unit

MC-Service



SWITCHES:
AMP UNIT
S101: LPF/HPF SELECT SWITCH... LPF-DEF-HPF
S102: HPF SELECT SWITCH... HPF-DEF
S851: RCA INPUT SELECT SWITCH... 2CH-4CH
S901: BFC SWITCH... LOW-HIGH
The underlined indicates the switch position.

NOTE:
□ Symbol indicates a resistor. No differentiation is made between chip resistors and discrete resistors.
⊖ Symbol indicates a capacitor. No differentiation is made between chip capacitors and discrete capacitors.


Decimal points for resistor and capacitor fixed are expressed as:
2.2-2R2
0.022-R022

10	9	8	7	6
5	4	3	2	1

Fig.6

GM-X404,X304

8. EXPLODED VIEW



MC-Service

Fig.7

GM-X404,X304**NOTE:**

- Parts marked by “*” are generally unavailable because they are not in our Master Spare Parts List.
- Parts marked by “⊙” are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

● Parts List(GM-X404/X1H/UC)

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
	1	Screw	BSZ30P050FZK	30	Holder	HNC5541	
	2	Screw(M3×6)	CBA1320	31	Holder	HNC5841	
	3	Screw(M3×12)	CBA1323	32	Heat Sink(Subheat Sink)	HNR1352	
	4	Cord Assy	HDE4427	33	Heat Sink(Subheat Sink)	HNR1353	
	5-8		34	Screw(M3×5)	CBA1330	
	9	Case	HNB1837	35	Heat Sink	HNR1339	
	10	Panel	HNB1838	36	Plate Unit	HXA7359	
	11	Panel	HNB1839	37	Pin Jack(CN852)	CKB1013	
	12,13		38	Pin Jack(CN851)	CKB1022	
	14	Spacer	HNV3975	39	Terminal(CN601)	CKE1036	
	15	Amp Assy	HWH1184	40	Holder	HNC5511	
	16	Screw(M3×10)	CBA1322	41	Screw	PPZ30P060FZK	
	17	Cord	CDE4610	42	Thermister(TH603)	CCX1013	
	18	Plug(CN301)	CKM1100	43	Diode(D609)	RBV-602L	
	19	Plug(CN861)	CKS1037	44	FET(Q610-613)	IRFIZ44G	
	20	Plug(CN862)	CKS1038	45	Thermister(TH601)	CCX1009	
	21	Plug(CN863)	CKS1618	46	Transistor(Q313-316)	2SD2343	
	22	Holder	CNC2218	47	Transistor(Q329-332)	2SB1587	
	23	Clamper	CNV1335	48	Transistor(Q325-328)	2SD2438	
	24	Holder	CNV4017	49	Screw	PPZ30P060FZK	
	25	Connector	HDE4428				
*	26	Fuse(FU1)	HEK0025				
	27	Holder	HNC5538				
	28	Holder	HNC5539				
	29	Holder	HNC5540				

GM-X404,X304

- The GM-X304/X1H/UC, GM-X404/X1H/EW and GM-X404/X1H/ES Parts Lists enumerate the parts which differ from those for the GM-X404/X1H/UC only. The parts other than those enumerated in the GM-X304/X1H/UC, GM-X404/X1H/EW and GM-X404/X1H/ES Parts Lists are identical with those in the GM-X404/X1H/UC Parts List, to which you are requested to refer, accordingly. The GM-X404/X1H/UC Parts List is given on page 15.

Mark No.	Description	GM-X404/X1H/UC Part No.	GM-X304/X1H/UC Part No.	GM-X404/X1H/EW Part No.	GM-X404/X1H/ES Part No.
	5 Cord Assy	HDE4419	HDE4419	HDE4419
*	6 Cord	HDE4423	HDE4423	HDE4423
	7 Fuse	HEK0030	HEK0030	HEK0030
	8 Cord	HDE4455	HDE4455	HDE4455
	10 Panel	HNB1838	HNB1838	HNB1838
	11 Panel	HNB1839	HNB1839	HNB1839
	12 Panel	HNB1870
	13 Panel	HNB1871
	15 Amp Assy	HWH1184	HWH1186	HWH1185	HWH1185
	35 Heat Sink	HNR1339	HNR1377	HNR1345	HNR1377
	36 Plate Unit	HXA7359	HXA7363	HXA7361	HXA7361
	37 Pin Jack(CN852)	CKB1013	CKB1011	CKB1011
	38 Pin Jack(CN851)	CKB1022	CKB1021	CKB1021	CKB1021
	39 Terminal(CN601)	CKE1036	CKE1035	CKE1035	CKE1035
	49 Screw	PPZ30P060FZK	PPZ30P060FZK	PPZ30P060FZK

9. PACKING METHOD




Fig.8

● **Parts List(GM-X404/X1H/UC)**

Mark No. Description	GM-X404/X1H/UC	GM-X304/X1H/UC	GM-X404/X1H/EW	GM-X404/X1H/ES
	Part No.	Part No.	Part No.	Part No.
1 Polyethylene Bag	HEG0009	HEG0009	HEG0009	HEG0009
2 Cord Assy(Output)	HDE4427	HDE4427	HDE4427	HDE4427
3 Cord Assy(Power Supply)	HDE4419	HDE4419	HDE4419
4 Screw Assy	HEA0003	HEA0003	HEA0003	HEA0003
4-1 Screw(×4)	BYC40P180FZK	BYC40P180FZK	BYC40P180FZK	BYC40P180FZK
4-2 Polyethylene Bag	HEG0011	HEG0011	HEG0011	HEG0011
5 Carton	HHG0020	HHG0019	HHG0021	HHG0022
6 Contain Box	HHL0020	HHL0019	HHL0021	HHL0022
7 Protector	HHP0001	HHP0001	HHP0001	HHP0001
* 8 Warranty Card	HRY1070	HRY1071
9 Owner's Manual	HRD0002	HRD0001	HRD0003	HRD0005

Owner's Manual

Part No.	Model	Language
HRD0001	GM-X304/X1H/UC	English, French
HRD0002	GM-X404/X1H/UC	English, French
HRD0003	GM-X404/X1H/EW	English, French, German, Dutch, Spanish, Swedish, Norwegian, Finnish, Italian
HRD0005	GM-X404/X1H/ES	English, French, Spanish, Arabic

GM-X404,X304

10. OPERATIONS AND CONNECTION(GM-X404/X1H/UC)




Fig. 9




Fig. 11




Fig. 10

Setting of this Unit

(Fig. 9)

- [1] Power Indicator**
The power indicator lights when the power is switched on.
- [2] RCA Input Select Switch**
For two-channel input, slide this switch to the left. For four-channel input, slide this switch to the right.
- [3] BFC (Beat Frequency Control) Switch**
If you hear a beat while listening to an AM broadcast with your car stereo, change the BFC switch using a small screwdriver.
- [4] Input Level Adjustment**
Adjusting the input level controls A and B will help match the output of the car stereo to the Pioneer amplifier. Input level control A is used to adjust the volume of speaker output A; Input level control B is used to adjust the volume of speaker output B. Normally, set the switch to the "500 mV" position. If the output is low even when the volume of the car stereo is turned up, turn these controls clockwise. If there is distortion when the volume of the car stereo is turned up, turn these controls clockwise.
 - If you only use one input pin plug, set the input level controls for speaker outputs A and B to the same position.

- Set the input level control to 500 mV when this amplifier is connected to a Pioneer car stereo with RCA output jacks. If the sound is too low or distorts, adjust the input level control.

[5] Speaker Out A: LPF (Low-Pass Filter)/HPF (High-Pass Filter) Select Switch
Set the LPF/HPF select switch as follows according to the type of the speaker that is connected to the speaker output connector and the car stereo system:

LPF/HPF Select Switch	Audio frequency range to be output	Speaker Type
LPF (left)	Very-low-frequency range	Sub-woofer
OFF (center)	Very-low-frequency range to high-frequency range	Other than sub-woofer
HPF (right)	Low-frequency range to high-frequency range	Other than sub-woofer

- Set the LPF/HPF select switch to the HPF (right) position if you want to cut the very-low-frequency range because it is not necessary for the speaker you use.

[6] Speaker Out A: Bass Boost Level Control
Bass boost level control can boost the level around the frequency selected by the bass boost frequency control to 0 to 12 dB.

[7] Speaker Out A: Bass Boost Frequency Control

You can select a bass boost frequency from 40 to 120 Hz with the bass boost control.

- [6] [7] can be adjusted only when the LPF/HPF select switch is set to a position other than HPF.

[8] Speaker Out B: HPF (High-Pass Filter) Select Switch

Set the HPF select switch as follows according to the car stereo system and the type of speaker connected to the speaker output:

HPF Select Switch	Audio frequency range to be output	Speaker Type
OFF (left)	Very-low-frequency range to high-frequency range	Sub-woofer
HPF (right)	Low-frequency range to high-frequency range	Other than sub-woofer

- Set the LPF/HPF select switch to the HPF (right) position if you want to cut the very-low-frequency range because it is not necessary for the speaker you use.

GM-X404, X304

Connecting the Unit

⚠ CAUTION

- Remove the negative (-) terminal of the battery to avoid the risk of short-circuit and damage to the unit.
- Secure the wiring with cable clamps or adhesive tape. To protect the wiring, wrap adhesive tape around them where they lie against metal parts.
- Do not route wires where they will get hot, for example where the heater will blow over them. If the insulation heats up, it may become damaged, resulting in a short-circuit through the vehicle body.
- Make sure that wires will not interfere with moving parts of the vehicle, such as the gearshift, handbrake or seat sliding mechanism.
- Do not shorten any leads. Otherwise the protection circuit may fail to work when it should.
- Never feed power to other equipment by cutting the insulation of the power supply wire to tap from the wire. The current capacity of the wire will be exceeded, causing overheating.
- Always use the special red battery power and ground wire [RD-222], which is sold separately. Connect the special red battery power cord directly to the car battery and the black ground wire to the car body. (The special red battery power and ground wire [RD-222] are designed so that the amplifier can be connected safely.)

⚠ To prevent damage

- Do not ground the speaker wire directly or connect a negative (-) wire for several speakers.
- Speakers to be connected to the amplifier should conform with the standards listed below. Otherwise damage will be caused to the speaker. The speaker impedance must be 2 to 8 ohms.

Speaker		Power
Channel	Type	
Four-channel	Sub-woofer	Nominal input: Min. 30 W
	Other than sub-woofer	Max. input: Min. 60 W
Two-channel	Sub-woofer	Nominal input: Min. 70 W
	Other than sub-woofer	Max. input: Min. 140 W
Three-channel Speaker output A	Sub-woofer	Nominal input: Min. 30 W
	Other than sub-woofer	Max. input: Min. 60 W
Three-channel Speaker output B	Sub-woofer	Nominal input: Min. 70 W
	Other than sub-woofer	Max. input: Min. 140 W

⚠ If many units are connected

- If you let the car engine idle for a long time with the car stereo on, the battery may go dead. Turn the car stereo off when the engine is idling.
- If the blue lead of the amplifier is connected to the power terminal through the ignition switch (12 VDC), the amplifier will always be on when the ignition is on—regardless of whether the car stereo is on or off. Because of this, the battery could go dead if you let the engine idle.
- This unit is for vehicles with a 12-volt battery and negative grounding. Before installing it in a recreational vehicle, truck, or bus, check the battery voltage.
- Install and route the separately sold special red battery wire [RD-222] as faraway as possible from the speaker wires. Install and route the separately sold special red battery wire and ground wire [RD-222], speaker wires, and the amplifier as faraway as possible from the antenna, antenna cable and tuner.

(Fig. 10)

- [9] Special red battery wire [RD-222] (sold separately)
After making all other connections at the amplifier, connect the battery lead terminal of the amplifier to the positive (+) terminal of the battery.
- [10] Ground wire (black) [RD-222] (sold separately)
Connect to metal body or chassis.
- [11] Fuse (Special red battery power wire: 30 A, Amplifier: 25 A)

- [12] Grommet
[13] Amplifier with RCA input pin jacks
[14] RCA input
[15] Car stereo with RCA output pin jacks
[16] External Output
For details on how to connect to RCA input jacks A and B, see the "Connecting the Speakers and Input wires" section.
If only input pin plug, do not connect anything to RCA input jack B.
- [17] White
[18] Red
[19] Connecting wires with RCA pin plugs (sold separately)
[20] RCA input pin jack A, B
[21] RCA output pin jacks
[22] Blue

Connect the male terminal of this wire to the blue wire of the car stereo (system control terminal). The female terminal can be connected to the auto-antenna relay control terminal. If the car stereo does not have a system remote control terminal, connect the male terminal to the power terminal through the ignition switch.

- [23] Speaker output terminal
See the "Connecting the Speakers and Input wires" section for speaker connection instructions.

Connecting the Power Terminal

- Always use the special red battery power and ground wire [RD-222], which is sold separately. Connect the special red battery power cord directly to the car battery and the black ground wire to the car body. (The special red battery power and ground wire [RD-222] are designed so that the amplifier can be connected safely.)

Pass the special red battery wire from the engine compartment to the interior of the vehicle.




Fig. 12

Connect the special red battery wire to the POWER terminal (+), and the black ground wire to the GND terminal (-).




Fig. 13

Fig. 14

- Securely fasten the special red battery wire and the ground wires with terminal screws.

Connecting the Speakers and Input wires

The speaker output mode can be four-channel, three-channel (stereo + mono) or two-channel (stereo, mono). To connect the speaker wires to suit the mode, connect the speakers according to figures on following pages.

GM-X404,X304




Fig. 15




Fig. 16

Four-channel mode (Fig. 15)

- [2] RCA Input Select Switch
For two-channel input, slide this switch to the left. For four-channel input, slide this switch to the right.
- [16] Output (Front/Rear)
If only one input pin plug is used, do not connect anything to RCA input jack B.
- [17] White
- [18] Red
- [19] Connecting wires with RCA pin plugs (sold separately)
- [21] RCA output pin jacks
- [24] Speaker out B: Speaker (right)
- [25] Speaker out B: Speaker (left)
- [26] Speaker out A: Speaker (left)
- [27] Speaker out A: Speaker (right)
- [28] Black cover
- [29] Black stripe
- [30] Green cover
- [31] Green stripe
- [32] To RCA input pin jacks
- [33] RCA input pin jack A
- [34] RCA input pin jack B
- Connect the front or rear output pin plugs to jacks [33] or [34], according to your system.
- [35] If only one input pin plug is used, do not connect anything to RCA input jack B.

Three-channel mode (Fig. 16)

- [2] RCA Input Select Switch
For two-channel input, slide this switch to the left. For four-channel input, slide this switch to the right.
- [16] Output (Front/Rear)
If only one input pin plug is used, do not connect anything to RCA input jack B.
- [17] White
- [18] Red
- [19] Connecting wires with RCA pin plugs (sold separately)
- [24] Speaker out B: Speaker (right)
- [25] Speaker out B: Speaker (left)
- [28] Black cover
- [29] Black stripe
- [30] Green cover
- [31] Green stripe
- [32] To RCA input pin jacks
- [33] RCA input pin jack A
- [34] RCA input pin jack B
- Connect the front or rear output pin plugs to jacks [33] or [34], according to your system.
- [35] If only one input pin plug is used, do not connect anything to RCA input jack B.
- [36] No connection
- [37] Speaker out A: Speaker (mono)




Fig. 17

Two-channel mode (stereo) (Fig. 17)

- [2] RCA Input Select Switch
Slide this switch to the left.
- [16] Output
- [17] White
- [18] Red
- [19] Connecting wires with RCA pin plugs (sold separately)
- [21] RCA output pin jacks
- [28] Black cover
- [29] Black stripe
- [30] Green cover
- [31] Green stripe
- [32] To RCA input pin jacks
- [33] RCA input pin jack A
- [36] No connection
- [38] Speaker (right)
- [39] Speaker (left)




Fig. 18

Two-channel mode (mono) (Fig. 18)

- [2] RCA Input Select Switch
Slide this switch to the left.
- [16] Output
- [17] White
- [18] Red
- [19] Connecting wires with RCA pin plugs (sold separately)
- [21] RCA output pin jacks
- [28] Black cover
- [29] Black stripe
- [30] Green cover
- [31] Green stripe
- [32] To RCA input pin jacks
- [33] RCA input pin jack A
- [36] No connection
- [40] Speaker (mono)

Installation

CAUTION

- Do not install in:
 - Places where it could injure the driver or passengers if the vehicle stops suddenly.
 - Places where it may interfere with the driver, such as on the floor in front of the driver's seat.
- Make sure that wires are not caught in the sliding mechanism of the seats, resulting in a short-circuit.
- Confirm that no parts are behind the panel when drilling a hole for installation of the amplifier. Protect all cables and important equipment such as fuel lines, brake lines and the electrical wiring from damage.
- Install tapping screws in such a way that the screw tip does not touch any wire. This is important to prevent wires from being cut by vibration of the car, which can result in fire.
- To ensure proper installation, use the supplied parts in the manner specified. If any parts other than the supplied ones are used, they may damage internal parts of the amplifier, or they may become loose and the amplifier may shut down.

11. OPERATIONS AND CONNECTION(GM-X304/X1H/UC)




Fig. 19




Fig. 21




Fig. 20

Setting of this Unit

(Fig. 19)

- [1] **Power Indicator**
The power indicator lights when the power is switched on.
- [2] **RCA Input Select Switch**
For two-channel input, slide this switch to the left. For four-channel input, slide this switch to the right.
- [3] **BFC (Best Frequency Control) Switch**
If you hear a beat while listening to an AM broadcast with your car stereo, change the BFC switch using a small screwdriver.
- [4] **Input Level Adjustment**
Adjusting the input level controls A and B will help match the output of the car stereo to the Pioneer amplifier. Input level control A is used to adjust the volume of speaker output A; Input level control B is used to adjust the volume of speaker output B. Normally, set the switch to the "500 mV" position. If the output is low even when the volume of the car stereo is turned up, turn these controls clockwise. If there is distortion when the volume of the car stereo is turned up, turn these controls clockwise.
• If you only use one input pin plug, set the input level controls for speaker outputs A and B to the same position.

- Set the input level control to 500 mV when this amplifier is connected to a Pioneer car stereo with RCA output jacks. If the sound is too low or distorts, adjust the input level control.

[5] **Speaker Out A: LPF (Low-Pass Filter)/HPF (High-Pass Filter) Select Switch**
Set the LPF/HPF select switch as follows according to the type of the speaker that is connected to the speaker output connector and the car stereo system:

LPF/HPF Select Switch	Audio frequency range to be output	Speaker Type
LPF (left)	Very-low-frequency range	Sub-woofer
OFF (center)	Very-low-frequency range to high-frequency range	Other than sub-woofer
HPF (right)	Low-frequency range to high-frequency range	Other than sub-woofer

- * Set the LPF/HPF select switch to the HPF (right) position if you want to cut the very-low-frequency range because it is not necessary for the speaker you use.

[6] **Speaker Out A: Bass Boost Level Control**
Bass boost level control can boost the level around 60 Hz to 0 to 12 dB.

- Bass boost level control can be adjusted only when the LPF/HPF select switch is set to a position other than HPF.

[7] **Speaker Out B: HPF (High-Pass filter) Select Switch**
Set the HPF select switch as follows according to the car stereo system and the type of speaker connected to the

HPF Select Switch	Audio frequency range to be output	Speaker Type
OFF (left)	Very-low-frequency range to high-frequency range	Other than subwoofer
HPF (right)	Low-frequency range to high-frequency range	Other than subwoofer

- * Set the HPF select switch to the HPF (right) position if you want to cut the very-low-frequency range because it is not necessary for the speaker you use.

speaker output:

GM-X404, X304

Connecting the Unit

⚠ CAUTION

- Remove the negative (-) terminal of the battery to avoid the risk of short-circuit and damage to the unit.
- Secure the wiring with cable clamps or adhesive tape. To protect the wiring, wrap adhesive tape around them where they lie against metal parts.
- Do not route wires where they will get hot, for example where the heater will blow over them. If the insulation heats up, it may become damaged, resulting in a short-circuit through the vehicle body.
- Make sure that wires will not interfere with moving parts of the vehicle, such as the gearshift, handbrake or seat sliding mechanism.
- Do not shorten any wires. Otherwise the protection circuit may fail to work when it should.
- Never feed power to other equipment by cutting the insulation of the power supply wire to tap from the wire. The current capacity of the wire will be exceeded, causing overheating.
- Be sure to use the special red battery wire supplied with the amplifier and connect directly to the battery. Use the supplied black ground wire and connect to the vehicle body. (The supplied special red battery and ground wires are designed so that the amplifier can be connected safely.)

⚠ To prevent damage

- Do not ground the speaker lead wire directly or connect a negative (-) lead wire for several speakers.
- Speakers to be connected to the amplifier should conform with the standards listed below. Otherwise damage will be caused to the speaker. The speaker impedance must be 2 to 8 ohms.

Speaker		Power
Channel	Type	
Four-channel	Sub-woofer	Nominal input: Min. 30 W
	Other than sub-woofer	Max. input: Min. 60 W
Two-channel	Sub-woofer	Nominal input: Min. 70 W
	Other than sub-woofer	Max. input: Min. 140 W
Three-channel Speaker output A	Sub-woofer	Nominal input: Min. 30 W
	Other than sub-woofer	Max. input: Min. 60 W
Three-channel Speaker output B	Sub-woofer	Nominal input: Min. 70 W
	Other than sub-woofer	Max. input: Min. 140 W

- This unit is for vehicles with a 12-volt battery and negative grounding. Before installing it in a recreational vehicle, truck, or bus, check the battery voltage.
- Install and route the sold separately special red battery wire supplied with the amplifier as faraway as possible from the speaker wires. Install and route the battery wire, ground wire, speaker wires, and the amplifier as faraway as possible from the antenna, antenna cable and tuner.

(Fig. 20)

- [8] Special red battery wire
After making all other connections at the amplifier, connect the battery lead terminal of the amplifier to the positive (+) terminal of the battery.
- [9] Ground wire (black)
Connect to metal body or chassis.
- [10] Fuse (Special red battery power wire: 30 A, Amplifier: 25 A)
- [11] Grommet
- [12] Car stereo with RCA output pin jacks
- [13] External Output
For details on how to connect to RCA input jacks A and B, see the "Connecting the Speakers and Input wires" section.
If only one input pin plug, do not connect anything to RCA input jack B.
- [14] White
- [15] Red
- [16] Connecting wires with RCA pin plugs (sold separately)
- [17] RCA input pin jack A, B

[18] Blue

Connect the male terminal of this wire to the blue wire of the car stereo (system control terminal). The female terminal can be connected to the auto-antenna relay control terminal. If the car stereo does not have a system remote control terminal, connect the male terminal to the power terminal through the ignition switch.

[19] Speaker output terminals

See the "Connecting the Speakers and Input wires" section for speaker connection instructions.

Connecting the Power Terminal

- Be sure to use the special red battery wire supplied with the amplifier and connect directly to the battery. Use the supplied black ground wire and connect to the vehicle body. (The supplied special red battery and ground wires are designed so that the amplifier can be connected safely.)

Pass the special red battery wire from the engine compartment to the interior of the vehicle.




Fig. 22

Connect the special red battery wire to the POWER terminal (+), and the black ground wire to the GND terminal (-).




Fig. 23

Fig. 24

- Securely fasten the special red battery lead and the ground wires with terminal screws.

Connecting the Speakers and Input wires

The speaker output mode can be four-channel, three-channel (stereo + mono) or two-channel (stereo, mono). Connect the speakers according to figures on following pages.

GM-X404,X304




Fig. 25




Fig. 26

Four-channel mode (Fig. 25)

- [2] RCA Input Select Switch
For two-channel input, slide this switch to the left. For four-channel input, slide this switch to the right.
- [13] Output (Front/Rear)
If only one input pin plug is used, do not connect anything to RCA input jack B.
- [14] White
- [15] Red
- [16] Connecting wires with RCA pin plugs (sold separately)
- [20] Speaker out B: Speaker (right)
- [21] Speaker out B: Speaker (left)
- [22] Speaker out A: Speaker (left)
- [23] Speaker out A: Speaker (right)
- [24] Black cover
- [25] Black stripe
- [26] Green cover
- [27] Green stripe
- [28] RCA input pin jack A
- [29] RCA input pin jack B
- Connect the front or rear output pin plugs to jacks [28] or [29], according to your system.
- [30] If only one input pin plug is used, do not connect anything to RCA input jack B.

Three-channel mode (Fig. 26)

- [2] RCA Input Select Switch
For two-channel input, slide this switch to the left. For four-channel input, slide this switch to the right.
- [13] Output (Front/Rear)
If only one input pin plug is used, do not connect anything to RCA input jack B.
- [14] White
- [15] Red
- [16] Connecting wires with RCA pin plugs (sold separately)
- [20] Speaker out B: Speaker (right)
- [21] Speaker out B: Speaker (left)
- [24] Black cover
- [25] Black stripe
- [26] Green cover
- [27] Green stripe
- [28] RCA input pin jack A
- [29] RCA input pin jack B
- Connect the front or rear output pin plugs to jacks [28] or [29], according to your system.
- [30] If only one input pin plug is used, do not connect anything to RCA input jack B.
- [31] No connection
- [32] Speaker out A: Speaker (mono)




Fig. 27




Fig. 28

Two-channel mode (stereo) (Fig. 27)

- [2] RCA Input Select Switch
Slide this switch to the left.
- [13] Output
- [14] White
- [15] Red
- [16] Connecting wires with RCA pin plugs (sold separately)
- [24] Black cover
- [25] Black stripe
- [26] Green cover
- [27] Green stripe
- [28] RCA input pin jack A
- [31] No connection
- [33] Speaker (right)
- [34] Speaker (left)

Two-channel mode (mono) (Fig. 28)

- [2] RCA Input Select Switch
Slide this switch to the left.
- [13] Output
- [14] White
- [15] Red
- [16] Connecting wires with RCA pin plugs (sold separately)
- [24] Black cover
- [25] Black stripe
- [26] Green cover
- [27] Green stripe
- [28] RCA input pin jack A
- [31] No connection
- [35] Speaker (mono)

Installation**⚠ CAUTION**

- Do not install in:
 - Places where it could injure the driver or passengers if the vehicle stops suddenly.
 - Places where it may interfere with the driver, such as on the floor in front of the driver's seat.
- Make sure that wires are not caught in the sliding mechanism of the seats, resulting in a short-circuit.
- Confirm that no parts are behind the panel when drilling a hole for installation of the amplifier. Protect all cables and important equipment such as fuel lines, brake lines and the electrical wiring from damage.
- Install tapping screws in such a way that the screw tip does not touch any wire. This is important to prevent wires from being cut by vibration of the car, which can result in fire.
- To ensure proper installation, use the supplied parts in the manner specified. If any parts other than the supplied ones are used, they may damage internal parts of the amplifier, or they may become loose causing the amplifier may start down.