



**JUMPER CONNECTIONS - BOTTOM SIDE**

Connect jumpers as shown when placed on the BOTTOM side of a one-sided PWB. Use AWG #30 or #28 insulated wire. Install jumpers in drilled-through VIA's. (Pad sizes exaggerated for clarity; component mounting holes shown for reference only.)

Title		
SW-OPA DISC OPAMP SMT(1) PWB		
Size	Number	Rev
	SWOPA2620PWB1	A
Date	Sun Jan 27, 2013	Drawn by D. Chisholm
SW-OPA DISC Opamp01_alt1.pcb	Sheet	of