



SOLDER MASK BOTTOM

JUMPER CONNECTIONS – TOP SIDE

Connect jumpers as shown when placed on the TOP side of a one-sided PWB.  
Use AWG #30 or #28 insulated wire.  
Install jumpers in drilled-through VIA's.  
(Pad sizes exaggerated for clarity; component mounting holes shown for reference only.)

Title SW-OPA DISC OPAMP SMT(1) PWB		
Size	Number SWOPA2620PWB1	Rev A
Date	Sun Jan 27, 2013	Drawn by D. Chisholm
SW-OPA DISC Opamp01_alt1.pcb	Sheet of	