


SCHEMATIC DIAGRAM Compact Disc Player CD2100



- NOTES:**
1. All resistors values are indicated in "ohm" (K=10<sup>3</sup>, M=10<sup>6</sup>).
  2. All capacitors values are indicated in "μF" (P=10<sup>-12</sup>).
  3. All voltages indicated on the schematics are measured under the following conditions.  
a. Use a V.T.V.M.
  4. This is a basic schematic diagram.
- b. All voltages ±10% with respect to chassis ground.  
c. No signals at input terminals.  
d. AC input at 230 or 240 volts 50Hz, and 120 volts 60Hz.

- PRODUCT SAFETY NOTE:**
1. Products marked with a ⚠ have special characteristics important to safety.
  2. Before replacing any of these components, read carefully the product safety notice of this service manual.
  3. Don't degrade the safety of the product through improper servicing.
  4. Before returning the appliance to the customer that exposed parts are acceptably insulated