



```
.MEAS RMS_Output_Power PARAM RMS_Output_Current*RMS_Output_Voltage
.MEAS TRAN RMS_Output_Voltage RMS V(OUT)
.MEAS TRAN RMS_Output_Current RMS I(R_LOAD)
.MEAS AC BW when V(OUT)=1/sqrt(2)
;ac oct 1000 1 1000000000
;op
.fourier 1K V(OUT)
.tran 0 4m 1m 5n
```