









TA-N88 / N88B TA-N88 / N88B

4.4. SCHEMATIC DIAGRAM – Power Supply Section –

Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un trame et une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- Note:
- All capacitors are in  $\mu\text{F}$  unless otherwise noted.  $\text{pF} = \mu\text{F}$  50WV or less are not indicated except for electrolytics.
  - All resistors are in ohms,  $\frac{1}{2}\text{W}$  unless otherwise noted.  $\text{k}\Omega = 1000\Omega$ ,  $\text{M}\Omega = 1000\text{k}\Omega$
  - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
  -  : nonflammable resistor.
  -  : fusible resistor.
  -  : B+ bus.
  -  : panel designation.
  -  : adjustment for repair.
  -  : B- bus.
  - Voltages are dc with respect to ground unless otherwise noted.

- Readings are taken under no signal conditions with a VOM (20k $\Omega$ /V).
- [ ] : AEP, UK model
- < > : US, Canadian model
- no mark: common
- Voltage variations may be noted due to normal production tolerances.
- Switch

Ref. No.	Switch	Position
S101	POWER	OFF

